NAW-2 STAINLESS STEEL SIGHT GLASS WITH DOME AND ROTOR

FEATURES

The NAW-2 sight glass with dome and rotor is designed for the visual inspection of flow for fluids inside piping. Made of stainless steel with a PP rotor and a glass dome, it is especially designed for process fluids.

The dome type provides particularly easy visibility. Horizontal mounting on installations. Unidirectional operation.

AVAILABLE MODELS

NAW-2: G 1/4" to G 1" G thread connections

LIMITS OF USE

| Fluid WP: | 16 bar |
|------------|--------------|
| Fluid WT°: | -5°C / +80°C |





DIRECTIVES AND MANUFACTURING STANDARDS

| OBJECT | Standard | |
|---------------------------------------|----------------------|--|
| Pressure Equipment Directive 97/23/EC | A3 § 3 non-submitted | |
| Stainless steel grade | EN 10213-4 | |
| Threaded connection | ISO 228 | |

FLOW-RATE TABLE

| DN | Minimum flow-rate | Maximum flow-rate | ΔP (v = 2 m/s) |
|--------|-------------------|-------------------|----------------|
| | (l/minute) | (l/minute) | bar |
| G 1/4" | 0.8 | 31 | 0.15 |
| G 3/8" | 0.9 | 41 | 0.18 |
| G 1/2" | 1.1 | 56 | 0.21 |
| G 3/4" | 1.4 | 95 | 0.2 |
| G 1" | 2.0 | 145 | 0.5 |

Information given as an indication only, and subject to possible modifications




NAW-2 STAINLESS STEEL SIGHT GLASS WITH DOME AND ROTOR

Flow


| DN | A | В | С | Weight (kg) |
|--------|----|----|----|----------------|
| G 1/4" | 76 | 63 | 65 | 0.5 |
| G 3/8" | 76 | 63 | 65 | 0.7 |
| G 1/2" | 76 | 63 | 65 | 1.1 |
| G 3/4" | 89 | 63 | 83 | 1.2 |
| G 1" | 89 | 63 | 83 | 1.4 |


DIMENSIONS (mm) AND WEIGHT (kg))



CONSTRUCTION

| No. | Name | Material |
|-----|-------------|----------------------|
| 1 | Body | 1.4408 SS |
| 2 | Cover | 1.4408 SS |
| 3 | Dome | Toughened glass |
| 4 | Gasket | FPM |
| 5 | Rotor guide | 1.4408 SS |
| 6 | Rotor | PP + 10% glass fibre |
| 7 | Bolt | Stainless steel |





ASSEMBLY AND SERVICING

Cut-off the piping upstream and downstream, depressurize, bleed and wait for it to cool down at ambient temperature before installation.

Loosen bolts, remove the cover, clean the glass dome and the internal parts.

Reassemble the parts in the reverse order.

Put the installation back in operation.

Information given as an indication only, and subject to possible modifications



ARMAT spol. s. r. o., Řetová 82, 561 41 Řetová armat@armat.cz, Tel.: +420 465 585 258 / 030 / 031, Fax +420465 585 254